



Frequently Asked Questions

Can I use another PC or APPLE?

The LumaCon package includes a HP PC and monitor. This is done because we can only guarantee the compatibility of external drivers, Windows versions etc. on this computer. Experience teaches us that unrequested OS updates can also affect drivers and therewith the functionality of the LumaCon.

Can I use the collimator in a vertical position?

Yes, the LumaCon can be used in horizontal and vertical position, enabling easier instalment of elements in a lens.

Can I extend the USB cables endless?

No, the maximum length of the USB cables between the PC & optical bench is approx. 1.5 meter. Longer cables might introduce USB errors.

Can I test (EF) lenses with an Image stabilizer?

This is not possible. Due to the fact that you are not applying power to the lens the IS element is in a random position. This random position does influence the optical axis of the lens negatively and therefore you cannot test the lens.

What is the Windows-password of the LumaCon PC?

Password is the same as the username: Administrator